


KASSE

EINGANG
AUSGANG

KASSE

EINGANG
AUSGANG



0 45

54 73

0 21

32 55

0 15



102

0 6

104

0 4

108

0 2

112

0 3 5 7
0 3 5 7

116

0 14
0 14

120

0 12 14 17
0 12 14 17

121

26

0
9

0
3

8 15
8 15

0 6

103

101

101

11

107

105

110

0 20

111

0 3 5 19

114

0 10

118

0 29

117

119

ROLL-
TREPPE